## MAE/ECE-5320 LAB 04: DC MOTOR FEEDFORWARD CONTROL AND ENCODER READING

#### **Excise 1: control motor direction**

A. Switch pin 2 to ON/OFF, and pin 3 to ON/OFF. Face the motor shaft and observe the rotation direction and complete the following table. (put *clockwise*, *counterclockwise* and *stationary*)

| Switch 1 | Switch 2 | Direction        |
|----------|----------|------------------|
| 1        | 0        | Counterclockwise |
| 0        | 1        | Clockwise        |
| 1        | 1        | Stationary       |
| 0        | 0        | stationary       |

B. Using switch 1 = 1 and switch 2 = 0, List the power voltage you used and describe the speed at each duty cycle value


| Power Voltage       | 5V          |  |
|---------------------|-------------|--|
| Duty Cycle<br>Value | Description |  |
| Value               |             |  |
| 0                   | no movement |  |
| 50                  | No movement |  |
| 150                 | slow        |  |
| 255                 | faster      |  |

| Power Voltage | 11V         |  |
|---------------|-------------|--|
| Duty Cycle    | Description |  |
| Value         |             |  |
| 0             | no movement |  |
| 50            | slow        |  |
| 150           | faster      |  |
| 255           | Very fast   |  |

### MAE/ECE-5320 LAB 04: DC MOTOR FEEDFORWARD CONTROL AND ENCODER READING

### **Excise 2: Open-loop speed control**

Construct the Simulink model using MATLAB Function block, saturation, and scope. Set the upper limit of saturation to 255, and lower limit to 0.



Try to write a MATLAB function script to generate the duty cycle function so that open-loop motor speed following  $\dot{\theta} = \omega_{max} sin(0.2 * t)$ . (Hint: duty cycle 255 is corresponding to maximum rotation speed.)


Attach your MATLAB Function script, block diagram, and scope response. Describe in 2-3 sentences how your motor is acting with respect to the scope in terms of speed amount, timing, and rotation direction,

★ Set scope settings: View=> Configuration Properties => Time. In time span select "<user-defined>" then click on the "<user-defined>" words and type in 50. Set "Time span orverrun



action to "Scroll". Apply the changes. Use the scaling button the main scope page to see the full function.

# MAE/ECE-5320 LAB 04: DC MOTOR FEEDFORWARD CONTROL AND ENCODER READING



The motor rotates counter clockwise when the scope sinusoid is positive and is stationary otherwise. The motor speed increases with sinusoid amplitude.